

ASSEMBLY INSTRUCTIONS



Model: 721839



WARNING! ENTRAPMENT OR CRUSHING RISK

Ensure there is no person, animal or item obstructing the area under the footrest before operating this device.



SAFETY INSTRUCTIONS

Please read these instructions carefully before operating.

- Ensure there is no person, animal or item obstructing the area under the footrest before operating this product.
- Improper use or installation may result in the risk of fire, electric shock and/or injury. We assume no liability for any eventual damages caused by improper use or inappropriate handling, or by any other non-compliance with the instructions in this manual.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the product.
- This product contains moving parts. Keep fingers, hair and body parts well clear from moving parts. To reduce the risk of injury, keep children and pets clear of the product when in use.
- Do not sit or place additional weight on the arms, back or open footrest.
- This product is very heavy. Only move this product by lifting the main body. Never drag by the footrest, back or arm rest.
- Return this product to the full upright position to stand safely and prevent a tripping hazard.
- Do not operate this product if damage is visible in any form.
- Do not modify or use unauthorised substitute parts.
- This product has been designed and intended for indoor residential use only. It is not suitable for commercial or outdoor use.
- This product is not intended to be used as part of a health care plan. Consult your medical professional before operating if you are taking medication or have physical limitations.
- Do not exceed the maximum 120kg weight limit for this product.



ELECTRICAL SAFETY

Please read these instructions carefully before operating.

- Never force the back or footrest to close faster than the electric motor.
- Before commencing cleaning or maintenance, ensure this product is disconnected from the power outlet and the back is in the full upright position.
- Disconnect this product from the power outlet before moving.
- Cease operation and disconnect from the power outlet if you ever detect a burning odour or smoke coming from the product.
- Do not operate this product if liquid spillage occurs on or around it. Disconnect from the power outlet and allow product to completely dry before reconnecting.
- Do not operate the power functions or charge station with wet hands.
- Check the condition of the power cord, electrical cords, transformer, plug and connector on a monthly basis. Do not operate if wear is visible.
- Ensure the power cord, electrical cords and transformer are clear of moving parts and not trapped underneath the base.
- Position the power cord to minimise a tripping hazard.
- Never attempt to open or disassemble electrical components.
- We recommend the use of a surge protector (not included).



Figure 2




Figure 3



Figure 4

ASSEMBLY INSTRUCTIONS

Please read these instructions carefully before assembling.

1. Assemble this product in an open space with room to move.
2. Remove the power supply cords and plugs tied to the metal post **B** located at the rear of the base and set aside for step 6.
3. Attach the seat backs to the base by sliding the metal receivers **A** over the metal posts **B** (Figure 1). Ensure both sides align before pushing down firmly to lock in place. The seat backs are heavy. Ask for help if you need assistance aligning the posts and receivers. Repeat across all seat backs.
4. Locate the power cords **C1** and **C2** attached to the seat back and the power cords **D1** and **D2** at the rear of the seat base (Figure 2). Connect **C1** to **D1** and **C2** to **D2** (Figure 3). **C1** and **D1** can be identified by the yellow tape.
5. Check all connections are firm and secure before velcroing down the flaps on the backs of all seats.
6. Retrieve the power supply cords and plugs **P** set aside in step 2. Connect to the outlet at the rear of each arm (Figure 4). Plug the power supply cord into a wall outlet. The 3 Seater and 2 Seater have a power supply cord for each arm. The Recliner only has one.
7. Turn the wall outlets on and ensure the red switches in each corner of the suite are on and lit up (Figure 4).
8. Your suite is now assembled and ready to be used. Please read the safety instructions before operating.




Figure 1

TROUBLESHOOTING

If you are having any issues please try the following solutions.


- Unplug the suite for 5 minutes to reset all electrical components.
- Check that all plugs are plugged into a wall outlet and are secure. Please check that the wall outlet is switched on. Try plugging the suite into a different wall outlet.
- Check the red switches at the rear of the suite are on.
- Check to ensure that all connection cords are properly connected, as per the step by step instructions. There are multiple connections, any of which being too loose may cause performance issues.
- Ensure no cords are pulled too tight. If the cord does not reach its destination with ease you may be trying to plug it into the wrong location. Please refer back to the step by step instructions to double check. If it is still too short/tight, please contact the store you purchased the suite from.
- Ensure there is nothing obstructing the recliner movement.
- Ensure the correct back is on the correct base – Eg: left back is on left base.
- The USB ports in the hand controller are low voltage. Please use an alternative source if you require a fast charge.
- Please check all connections before contacting the store for more help.

If the suite continues to fail please contact the store it was originally purchased from.

OPERATION INSTRUCTIONS

Hand Controller

Hand controllers are located on the outside of armrests.



Number	Functionality
1	Headrest forward
2	Headrest back
3	Lumbar forward
4	Lumbar back
5	Recliner open
6	Recliner close
7	Home
8	Lock
9	USB port

Congratulations
on your purchase

Assembly Instructions

Synargy is a registered responsible supplier on ERAC. Electrical components within our products have been tested and comply with all legal requirements imposed for electrical safety and EMC.

synargy[®]
Furniture that fits your life